



**Hewlett Packard**  
Enterprise

# **HPE Security ArcSight Connectors**

SmartConnector for Cisco Content Services  
Switch Syslog (Legacy)

Configuration Guide

May 15, 2017

## Configuration Guide

### SmartConnector for Cisco Content Services Switch Syslog (Legacy)

May 15, 2017

Copyright © 2006 – 2017 Hewlett Packard Enterprise Development LP

#### Warranty

The only warranties for Hewlett Packard Enterprise products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. Hewlett Packard Enterprise Development LP shall not be liable for technical or editorial omissions contained herein. The information contained herein is subject to change without notice. The network information used in the examples in this document (including IP addresses and hostnames) is for illustration purposes only. Hewlett Packard Enterprise Development LP products are highly flexible and function as you configure them. The accessibility, integrity, and confidentiality of your data is your responsibility. Implement a comprehensive security strategy and follow good security practices. This document is confidential.

#### Restricted Rights Legend

Confidential computer software. Valid license from Hewlett Packard Enterprise Development LP required for possession, use or copying. Consistent with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical data for Commercial Items are licensed to the U.S. Government under vendor's standard commercial license.

Follow this link to see a complete statement of Hewlett Packard Enterprise Development LP copyrights, trademarks and acknowledgements:

<https://www.protect724.hpe.com/docs/DOC-13026>.

## Revision History

---

Date	Description
05/15/2017	Marked connector as Legacy as CSS is no longer supported by Cisco.
11/30/2016	Updated installation procedure for setting preferred IP address mode.
05/15/2015	Added new parameters for Syslog File.
02/16/2015	Added parameter for Syslog Daemon connector configuration.
05/15/2012	Added new installation procedure.
02/11/2010	Added support for FIPS Suite B and CEF File transport.
06/30/2009	Added global update to installation procedure.
02/11/2009	Clarified platforms supported for connector installation.

---

---

## SmartConnector for Cisco Content Services Switch Syslog (Legacy)

---

This guide provides information for installing the SmartConnector for Cisco Content Services Switch Syslog and configuring the device for syslog event collection. Cisco CSS 11500 Series Content Services Switches are supported.

### Product Overview

As the premiere switch for the Cisco Web Network Services Software, the CSS 11500 Series helps businesses build global Web networks optimized for content delivery and e-commerce. The CSS 11500 Series can help to ensure availability, optimize utilization, reduce latency, increase scalability, and enhance security for Websites, server farms, cache clusters, and firewall systems.

The Cisco Content Services Switch (CSS) generates log messages to assist you with debugging and monitoring operations. By default, the CSS saves boot and subsystem event log messages to log files on its hard or Flash disk. The content of these files is recorded in ASCII text. You also can configure the CSS to send log messages to an active CSS session, e-mail address, or another host system. The maximum size of a log file is 50 MB for hard disk based systems and 10 MB for Flash disk based systems.

The subsystem log messages are subsystem events that occur during the operation of the CSS. The CSS saves these messages in the sys.log file, created when the first loggable subsystem event occurs. The CSS determines which subsystem messages to log by its configured logging level. By default, the CSS logs events on all subsystems with a level of warning. The warning level designates that the CSS logs fatal, alert, critical, error, and warning messages for the subsystem. You have the option to log subsystem messages at a different level than the default warning level. The level you specify instructs the CSS to log subsystem activity that occurs at that level and the activity greater than that level.

In addition to informational messages, the CSS also logs notice, warning, error, critical, alert, and fatal messages.

### Configuration

#### Configuring and Enabling Logging

To configure and enable Cisco Content Switch logging:

- 1 Specify the disk buffer size (0 to 64000).

Example: `logging buffer 1000`

- 2 Select a CSS subsystem; determine which type of activity to log (default is all) and type of event (default is warning).

Valid subsystems include: `acl, all, app, boomerang, buffer, cdp, chassis, circuit, csdpeer, dhcp, dql, fac, flowagent, flowmgr, fp-driver, hfg, ipv4, keepalive, natmgr, netman, netmgr, nql, ospf, pcm, portmapper, proximity, publish, radius, redundancy, reporter, replicate, rip,`

```
security, ssl-accel, slr, sntp, sshd, syssoft, urg=ql, vlanmgr, vpm,  
vrrp, wcc
```

Valid levels include: fatal = 0, alert = 1, critical = 2, error = 3, warning = 4, notice = 5, info = 6, and debug = 7.

Example: `logging subsystem rip level alert-1`

- 3 Specify the destination (`disk`, `host`, or `line`) to which you want to log subsystem activity.

You can specify a disk filename (new or existing filename in the log directory), a host ip address or host name (of the syslog server), or a log line (a CSS active session).

Examples:

```
logging disk stubs  
logging host 192.168.11.3  
logging host myhost.domain.com  
logging line vt1
```

## Configuring Cisco CSS to Send Syslog Events

To configure a Cisco Content Switch to send events:

- 1 Telnet to your Cisco Content Switch machine.
- 2 Within the console, enter enable mode by entering `enable` or `en`.
- 3 Enter configuration mode by entering `configure terminal` or `conf t`.
- 4 Set the location where you want to send Syslog events by entering the following:

```
logging <SyslogServerIPAddress>=>
```

Where `<SyslogServerIPAddress>` is the IP address of the Syslog server.

- 5 Set which messages are sent to the Syslog server by entering the following:

```
logging trap <MessageLevel>
```

Where `<MessageLevel>` is the level to be logged, such as alerts or debugging.

## Configure the Syslog SmartConnectors

The three ArcSight Syslog SmartConnectors are:

- Syslog Daemon
- Syslog Pipe
- Syslog File

## The Syslog Daemon SmartConnector

The Syslog Daemon SmartConnector is a syslogd-compatible daemon designed to work in operating systems that have no syslog daemon in their default configuration, such as Microsoft Windows. The SmartConnector for Syslog Daemon implements a UDP receiver on port 514 (configurable) by default that can be used to receive syslog events. Use of the TCP protocol or a different port can be configured manually.

If you are using the SmartConnector for Syslog Daemon, simply start the connector, either as a service or as a process, to start receiving events; no further configuration is needed.



Messages longer than 1024 bytes may be split into multiple messages on syslog daemon; no such restriction exists on syslog file or pipe.

## The Syslog Pipe and File SmartConnectors

When a syslog daemon is already in place and configured to receive syslog messages, an extra line in the syslog configuration file (`rsyslog.conf`) can be added to write the events to either a **file** or a system **pipe** and the ArcSight SmartConnector can be configured to read the events from it. **In this scenario, the ArcSight SmartConnector runs on the same machine as the syslog daemon.**

The **Syslog Pipe** SmartConnector is designed to work with an existing syslog daemon. This SmartConnector is especially useful when storage is a factor. In this case, syslogd is configured to write to a named pipe, and the Syslog Pipe SmartConnector reads from it to receive events.

The **Syslog File** SmartConnector is similar to the Pipe SmartConnector; however, this SmartConnector monitors events written to a syslog file (such as `messages.log`) rather than to a system pipe.

## Configure the Syslog Pipe or File SmartConnector

This section provides information about how to set up your existing syslog infrastructure to send events to the ArcSight Syslog Pipe or File SmartConnector.

The standard UNIX implementation of a syslog daemon reads the configuration parameters from the `/etc/rsyslog.conf` file, which contains specific details about which events to write to files, write to pipes, or send to another host. First, create a pipe or a file; then modify the `/etc/rsyslog.conf` file to send events to it.

### For syslog pipe:

- 1 Create a pipe by executing the following command:

```
mkfifo /var/tmp/syspipe
```

- 2 Add the following line to your `/etc/rsyslog.conf` file:

```
*.debug /var/tmp/syspipe
```

or

```
*.debug |/var/tmp/syspipe
```

depending on your operating system.

- 3 After you have modified the file, restart the syslog daemon either by executing the scripts `/etc/init.d/syslogd stop` and `/etc/init.d/syslogd start`, or by sending a `configuration restart` signal.

On RedHat Linux, you would execute:

```
service syslog restart
```

On Solaris, you would execute:

```
kill -HUP `cat /var/run/syslog.pid`
```

This command forces the syslog daemon to reload the configuration and start writing to the pipe you just created.

#### For syslog file:

Create a file or use the default for the file into which log messages are to be written.

After editing the `/etc/rsyslog.conf` file, be sure to restart the syslog daemon as described above.

When you follow the SmartConnector Installation Wizard, you will be prompted for the absolute path to the syslog file or pipe you created.

## Install the SmartConnector

The following sections provide instructions for installing and configuring your selected SmartConnector.

### Syslog Installation

Install this SmartConnector (on the syslog server or servers identified in the *Configuration* section) using the SmartConnector Installation Wizard appropriate for your operating system. The wizard will guide you through the installation process. When prompted, select one of the following **Syslog** connectors (see *Configure the Syslog SmartConnectors* in this guide for more information):

- Syslog Daemon
- Syslog Pipe
- Syslog File

Because all syslog SmartConnectors are sub-connectors of the main syslog SmartConnector, the name of the specific syslog SmartConnector you are installing is not required during installation.

The syslog daemon connector by default listens on port 514 (configurable) for UDP syslog events; you can configure the port number or use of the TCP protocol manually. The syslog pipe and syslog file connectors read events from a system pipe or file, respectively. Select the one that best fits your syslog infrastructure setup.

### Prepare to Install Connector

Before you install any SmartConnectors, make sure that the ArcSight products with which the connectors will communicate have already been installed correctly (such as ArcSight ESM or ArcSight Logger).

For complete product information, read the *Administrator's Guide* as well as the *Installation and Configuration* guide for your ArcSight product before installing a new SmartConnector. If you are adding a connector to the ArcSight Management Center, see the *ArcSight Management Center Administrator's Guide* for instructions, and start the installation procedure at "Set Global Parameters (optional)" or "Select Connector and Add Parameter Information."

Before installing the SmartConnector, be sure the following are available:

- Local access to the machine where the SmartConnector is to be installed
- Administrator passwords

## Install Core Software

Unless specified otherwise at the beginning of this guide, this SmartConnector can be installed on all ArcSight supported platforms; for the complete list, see the *SmartConnector Product and Platform Support* document, available from the HPE SSO and Protect 724 sites.

- 1 Download the SmartConnector executable for your operating system from the HPE SSO site.
- 2 Start the SmartConnector installation and configuration wizard by running the executable.




When installing a syslog daemon SmartConnector in a UNIX environment, run the executable as 'root' user.

---

Follow the wizard through the following folder selection tasks and installation of the core connector software:

Introduction  
Choose Install Folder  
Choose Shortcut Folder  
Pre-Installation Summary  
Installing...

- 3 When the installation of SmartConnector core component software is finished, the following window is displayed:



## Set Global Parameters (optional)

If you choose to perform any of the operations shown in the following table, do so before adding your connector. You can set the following parameters:

Global Parameter	Setting
Set FIPS mode	Set to 'Enable' to enable FIPS compliant mode. To enable FIPS Suite B Mode, see the SmartConnector User Guide under "Modifying Connector Parameters" for instructions. Initially, this value is set to 'Disable'.
Set Remote Management	Set to 'Enable' to enable remote management from ArcSight Management Center. When queried by the remote management device, the values you specify here for enabling remote management and the port number will be used. Initially, this value is set to 'Disable'.
Remote management listener port	The remote management device will listen to the port specified in this field. The default port number is 9001.
Preferred IP Version	If both IPv4 and IPv6 IP addresses are available for the local host (the machine on which the connector is installed), you can choose which version is preferred. Otherwise, you will see only one selection. When both values are present, the initial setting is IPv4.

After making your selections, click **Next**. A summary screen is displayed. Review the summary of your selections and click **Next**. Click **Continue** to return to the "Add a Connector" window. Continue the installation procedure with "Select Connector and Add Parameter Information."

## Select Connector and Add Parameter Information

- 1 Select **Add a Connector** and click **Next**. If applicable, you can enable FIPS mode and enable remote management later in the wizard after SmartConnector configuration.
- 2 Select **Syslog Daemon, Pipe, or File** and click **Next**.

### 3 Enter the required SmartConnector parameters to configure the SmartConnector, then click **Next**.

<b>Syslog Daemon Parameters</b>	<i>Network port</i>	The SmartConnector for Syslog Daemon listens for syslog events from this port.
	<i>IP Address</i>	The SmartConnector for Syslog Daemon listens for syslog events only from this IP address (accept the default (ALL) to bind to all available IP addresses).
	<i>Protocol</i>	The SmartConnector for Syslog Daemon uses the selected protocol (UDP or Raw TCP) to receive incoming messages.
	<i>Forwarder</i>	Change this parameter to 'true' only if the events being processed are coming from another SmartConnector sending to a CEF Syslog destination, and that destination also has CEF forwarder mode enabled. That allows attributes of the original connector to be retained in the original agent fields.
<b>Syslog Pipe Parameter</b>	<i>Pipe Absolute Path Name</i>	Absolute path to the pipe, or accept the default: /var/tmp/syspipe
<b>Syslog File Parameters</b>	<i>File Absolute Path Name</i>	<p>Enter the full path name for the file from which this connector will read events or accept the default: \var\adm\messages (Solaris) or \var\log\messages (Linux).</p> <p>A wildcard pattern can be used in the file name; however, in realtime mode, rotation can occur only if the file is over-written or removed from the folder. Realtime processing mode assumes following external rotation.</p> <p>For date format log rotation, the device writes to 'filename.timestamp.log' on a daily basis. At a specified time, the device creates a new daily log and begins to write to it. The connector detects the new log and terminates the reader thread to the previous log after processing is complete. The connector then creates a new reader thread to the new 'filename.timestamp.log' and begins processing that file. To enable this log rotation, use a date format in the file name as shown in the following example:</p> <pre>filename 'yyyy-MM-dd' .log;</pre> <p>For index log rotation, the device writes to indexed files - 'filename.log.001', 'filename.log.002', 'filename.log.003', and so on. At startup, the connector processes the log with highest index. When the device creates a log with a greater index, the connector terminates the reader thread to the previous log after processing completes, creates a thread to the new log, and begins processing that log. To enable this log rotation, use an index format, as shown in the following example:</p> <pre>filename '%d,1,99,true' .log;</pre> <p>Specifying 'true' indicates that it is allowed for the index to be skipped; for example, if 5 appears before 4, processing proceeds with 5 and will not read 4, even if 4 appears later. Use of 'true' is optional.</p>
	<i>Reading Events Real Time or Batch</i>	Specify whether file is to be read in batch or realtime mode. For batch mode, all files are read from the beginning. The 'Action Upon Reaching EOF' and 'File Extension if Rename Action' parameters apply for batch mode only.
	<i>Action Upon Reaching EOF</i>	For batch mode, specify 'None', 'Rename', or 'Delete' as the action to be performed to the file when the connector has finished reading and reaches end of file (EOF). For realtime mode, leave the default value of 'None' for this parameter.
	<i>File Extension If Rename Action</i>	For batch mode, specify the extension to be added to the file name if the action upon EOF is 'Rename' or accept the default value of '.processed'.

## Select a Destination

- 1 The next window asks for the destination type; select a destination and click **Next**. For information about the destinations listed, see the *ArcSight SmartConnector User Guide*.

- 2 Enter values for the destination. For the ArcSight Manager destination, the values you enter for **User** and **Password** should be the same ArcSight user name and password you created during the ArcSight Manager installation. Click **Next**.
- 3 Enter a name for the SmartConnector and provide other information identifying the connector's use in your environment. Click **Next**. The connector starts the registration process.
- 4 If you have selected ArcSight Manager as the destination, the certificate import window for the ArcSight Manager is displayed. Select **Import the certificate to the connector from destination** and click **Next**. (If you select **Do not import the certificate to connector from destination**, the connector installation will end.) The certificate is imported and the **Add connector Summary** window is displayed.

## Complete Installation and Configuration

- 1 Review the **Add Connector Summary** and click **Next**. If the summary is incorrect, click **Previous** to make changes.
- 2 The wizard now prompts you to choose whether you want to run the SmartConnector as a stand-alone process or as a service. If you choose to run the connector as a stand-alone process, select **Leave as a standalone application**, click **Next**, and continue with step 5.
- 3 If you chose to run the connector as a service, with **Install as a service** selected, click **Next**. The wizard prompts you to define service parameters. Enter values for **Service Internal Name** and **Service Display Name** and select **Yes** or **No** for **Start the service automatically**. The **Install Service Summary** window is displayed when you click **Next**.
- 4 Click **Next** on the summary window.
- 5 To complete the installation, choose **Exit** and Click **Next**.

For instructions about upgrading the connector or modifying parameters, see the *SmartConnector User Guide*.

## Run the SmartConnector

SmartConnectors can be installed and run in stand-alone mode, on Windows platforms as a Windows service, or on UNIX platforms as a UNIX daemon, depending upon the platform supported. On Windows platforms, SmartConnectors also can be run using shortcuts and optional Start menu entries.

If the connector is installed in stand-alone mode, it must be started manually and is not automatically active when a host is restarted. If installed as a service or daemon, the connector runs automatically when the host is restarted. For information about connectors running as services or daemons, see the *ArcSight SmartConnector User Guide*.

To run all SmartConnectors installed in stand-alone mode on a particular host, open a command window, go to `$ARCSIGHT_HOME\current\bin` and run: `arcsight connectors`

To view the SmartConnector log, read the file `$ARCSIGHT_HOME\current\logs\agent.log`; to stop all SmartConnectors, enter `Ctrl+C` in the command window.

## Device Event Mapping to ArcSight Fields

The following section lists the mappings of ArcSight data fields to the device's specific event definitions. See the *ArcSight Console User's Guide* for more information about the ArcSight data fields.

### Cisco Content Services Switch Field Mappings

ArcSight ESM Field	Device-Specific Field
Additional data	initSeq
Additional data	masterAddress
Additional data	number1
Additional data	number2
Additional data	number3
Additional data	number4
Additional data	powerSupply
Additional data	replayPort
Additional data	router
Additional data	synCnt
Additional data	synPort
Additional data	vrid
Additional data	whatisthis
Additional data	whatisthis2
ArcSight Severity (High)	2 or 3
ArcSight Severity (Low)	5 or 6
ArcSight Severity (Medium)	4
ArcSight Severity (Very High)	0 or 1
ArcSight Severity (Very Low)	7
Destination Address	destination IP address
Destination Host Name	destination host
Destination Mac Address	destination mac
Destination Port	destination port
Destination Process Name	process Id
Destination User Name	destination user
Device Action	action taken by the device
Device Custom Date 1	timestamp
Device Event Class Id	loglevel
Device Facility	subsystem
Device Inbound Interface	interface
Device Product	'CSS'
Device Receipt Time	eventTime
Device Severity	loglevel (0=Fatal, 1=Alert, 2=Critical, 3=Error, 4=Warning, 5=Notice, 6=Informational, 7=Debug)
Device Vendor	'CISCO'
External Id	eventId
Name	message
Source Address	source IP address
Source Port	source port

<b>ArcSight ESM Field</b>	<b>Device-Specific Field</b>
Source User Name	source user

---